






ATTENZIONE - ATTENTION - ACHTUNG

- Per lo smontaggio degli utensili utilizzare sempre la chiave di contrasto come indicato nel manuale d'uso.
- For disassembly of the tools use always the contrast key as mentioned in the user instructions.
- Fuer das Abmontieren der Werkzeuge immer den Gegenschlüssel benutzen wie in der Bedienungsanleitung erwaeht.

PER PORTAUTENSILI MODULARI MTSK-40 VEDI PAG. TBL300-1-40
 FOR MTSK-40 QUIK CHANGE TOOLHOLDERS CLAMPINGS SEE PAGE TBL300-1-40
 FUER MTSK-40 MODULARE WERKZEUGAUFNAHMEN SIEHE SEITE TBL300-1-40

Cod. MT	Mandrino Spindle Spindel	I (n1:n2)	RPM max n2	Coppia Max Max Torque Max Drehmoment M2 (Nm)	Lubrificazione int. Coolant through Innenkuehlung Pmax (bar)	Lubrificazione est. Ext. coolant Aussenkuehlung	B	CHIAVI NON INCLUSE Keys not included Schluesel nicht einbegriffen	
TKW0521140	MTSK-40	1:1	6000	65	-	X	54.5	CHUB46	OKU0650004 *
TKW0521240	MTSK-40	1:1	6000	65	70	X	67	CHUB46	OKU0650004 *

• Chiave inclusa
• Key included
• Schluesel inbegriffen

TAKISAWA
 MOD: TMM200/250 - TNR200

MODULO MOTORIZZATO ASSIALE MTSK PER CONTROMANDRINO VD140
 Axial MTSK driven tool for subspindle VD140
 Axial MTSK angetriebenes Werkzeug fuer Gegenspindel VD140

Subject to change without notice.

M.T. srl
 Via Casino Albini 480
 Tel. 0541/956034-957884
 Fax 0541/956341
 47842 S. GIOVANNI IN M. (RN)
 e-mail: mtma@mtmarchetti.com
 http://www.mtmarchetti.com



TKW 155-3-15-K