

ATTENZIONE - ATTENTION - ACHTUNG

- Per lo smontaggio degli utensili utilizzare sempre la chiave di contrasto come indicato nel manuale d'uso.
- For disassembly of the tools use always the contrast key as mentioned in the user instructions.
- Fuer das Abmontieren der Werkzeuge immer den Gegenschlüssel benutzen wie in der Bedienungsanleitung erwäehnt.

• Chiave inclusa

• Key included

• Schlüssel inbegriffen

Cod. MT	Mandrino Spindel	I	RPM	Coppia Max Max Torque Max Drehmoment	N°Utensili N°Tools N°Werkzeuge	Reversibile lato mandrino/contromandrino Reversible sub/main spindle side Umkehrbare Spindel-seite/ Gegenspindel-seite	Lubr.esterna Ext. coolant Aussenkuehlung	A	B	CHIAVI NON INCLUDE Keys not included Schlüssel nicht einbegriffen		
										CHUB36	CHSTER25	-
MNL1060225	ER25	1:1	10000	40Nm	2	X	X	137.96	68	CHUB36	CHSTER25	-
MNL1060325	ERA25	1:1	10000	40Nm	2	X	X	126.5	68	CHUB38	CHUB27	CHTAER25ZC •
MNL1240225	ER25+ER25	1:1	10000	40Nm	2+2	X	X	137.96	137.96	CHUB36	CHSTER25	-
MNL1240325	ERA25+ERA25	1:1	10000	40Nm	2+2	X	X	126.5	126.5	CHUB38	CHUB27	CHTAER25ZC •

DMG-MORI


NL1500/2000/2500/3000 12 STAZIONI - NLX1500/2000/2500/3000 12 STAZIONI - NLX4000 - NZL2000/2500 - NZX2500 (BMT60)
NT4200/4250/4300/5400 - NTX2000/2500/3000 2ND GEN. 10ST. - CTX2500 (BMT60)

MODULO MOTORIZZATO ASSIALE 2 USCITE IN Y 10000 RPM

Axial Single side twin head driven tool in Y 10000 rpm

Axial angetriebenes Werkzeug 2 Ausgaenge in Y 10000 rpm

Subject to change without notice.



M.T. srl

Via Casino Albini 480

Tel. 0541/956034-957884

Fax 0541/956341

47842 S. GIOVANNI IN M. (RN)

e-mail: mtma@mtmarchetti.com

http://www.mtmarchetti.com



MNL260-1-11