



ATTENZIONE - ATTENTION - ACHTUNG

- Per lo smontaggio degli utensili utilizzare sempre la chiave di contrasto come indicato nel manuale d'uso.
- For disassembly of the tools use always the contrast key as mentioned in the user instructions.
- Fuer das Abmontieren der Werkzeuge immer den Gegenschlüssel benutzen wie in der Bedienungsanleitung erwäehnt.

- Chiave inclusa
- Key included
- Schlüssell einbegriffen

Cod. MT	Mandrino Spindle Spindel	I (n1:n2)	RPM max n2	Coppia Max Max Torque Max Drehmoment M2 (Nm)	Reversibile lato mandrino/contromandrino Reversible sub/main spindle side Umkehrbare Spindel-seite/ Gegenspindel-seite	Lubrificazione int. Coolant through Innenkuehlung Pmax (bar)	Lubr.esterna Ext. coolant Aussenkuehlung	A	A1	B	D	L	CHIAVI NON INCLUDE Keys not included Schlüssell nicht einbegriffen		
TKW 0010125	ER25	1:1	6000	65	X	-	X	91.16	-	57	-	-	-	CHSTER25	OKU0650004
TKW 0010132	ER32	1:1	6000	65	X	-	X	93.66	-	57	-	-	-	CHSTER32	OKU0650004
TKW 0010140	ER40	1:1	6000	65	X	-	X	98.16	-	57	-	-	-	CHSTER40	OKU0650004
TKW 0010325	ERA25	1:1	6000	65	X	-	X	65	-	57	-	-	CHUB27	CHTAER25ZC	OKU0650004
TKW 0010225	ER25	1:1	6000	65	X	70	X	91.16	-	67	-	-	-	CHSTER25	OKU0650004
TKW 0010232	ER32	1:1	6000	65	X	70	X	93.66	-	67	-	-	-	CHSTER32	OKU0650004
TKW 0010240	ER40	1:1	6000	65	X	70	X	98.16	-	67	-	-	-	CHSTER40	OKU0650004
TKW 0010425	ERA25	1:1	6000	65	X	70	X	65	-	67	-	-	CHUB27	CHTAER25ZC	OKU0650004
TKW 0010516	Ø16x17	1:1	6000	65	X	-	X	-	67.5	-	16	17	-	CH_VTCROCE_M08	OKU0650004
TKW 0010522	Ø22x19	1:1	6000	65	X	-	X	-	67.5	-	22	19	-	CH_VTCROCE_M10	OKU0650004
TKW 0010527	Ø27x21	1:1	6000	65	X	-	X	-	70	-	27	21	-	CH_VTCROCE_M12	OKU0650004

TAKISAWA
MOD: TCY160/200

MODULO MOTORIZZATO ASSIALE
Axial driven tool
Axial angetriebenes Werkzeug

Subject to change without notice.

M.T. srl

Via Casino Albini 480
Tel. 0541/956034-957884
Fax 0541/956341
47842 S. GIOVANNI IN M. (RN)
e-mail: mtma@tmarchetti.com
http://www.tmmarchetti.com



TKW 150-1-10